

PARKER 180

One pen. One point. Two ways to write.

The pen that writes two ways...

Unique design. The reverse-taper design of the slender 22K gold electroplated or stainless steel case lends a look of space age efficiency and performance.



Choosing writing widths. When the metal nib guide is on top, the pen will write a **medium** width line.



Rotate the pen 180 degrees so the black nib guide is on top and your pen will put down an **extra fine** line.

Filling your Parker 180

The pen is equipped with a removable metal filling unit called a converter and one Parker Super Quink Ink cartridge. These units are interchangeable and enable you to fill your Parker 180 in two different ways:

From an ink bottle Remove cap and unscrew barrel. Immerse the point in ink until the metal collar is covered. Press ribbed bar four times, remove from ink. Remove excess ink from point section with absorbent tissue.

With Parker Super Quink Ink Cartridges. Take off cap, unscrew barrel and remove filling unit. Push cartridge in firmly, wide end first, until you feel it seat itself. Replace barrel, allow a few seconds for ink to reach the point.